

目 录 CONTENTS

cartridge valves

插 装 阀

Sequence valves	
一、逻辑阀 (LCV).....	1-2
Pressure control valves	
二、压力控制阀	
Directly relief valves	
1. 直动溢流阀	
(1) YF04-00-00	3
(2) YF04-01-00	4
(3) YF04-02-00	5
(4) YF04-03-00	6
(5) YF04-04-00	7
(6) YF06-00-00	8
(7) YF06-01-00	9
(8) YF06-02-00	10
(9) YF08-00-00	11
(10) YF10-00-00	12
(11) YF10-01-00	13
pilot-operated relief valve	
2. 直动溢流阀	
(1) XDYF15-01-00	14
(2) XDYF15-02-00	15
(3) XDYF20-00-00	16
(4) XDYF20-01-00	17
(5) XDYF25-01-00	18
(6) XDYF25-02-00	19
(7) CDBJ-F15-010	20
(8) CDBJ-F15-030	21
(9) CDBJ-F20-020	22
(10) CDBJ-F20-023	23
3. 减压阀: JF06-00-00	24
Pressure reduce valve	
4. 负载控制阀: Load control valves	
(1) PF-12-01-00	25
(2) PF-12-02-00	26
(3) PF-12-03-00	27
(4) PF-12-04-00	28
Directional valves	
三、方向控制阀	
Check valve	
1. 单向阀	
(1) DF06-01-00	29
(2) DF06-02-00	30
(3) DF06-03-00	31
(4) DF10-01-00	32